

Mark II Manometer Installation

1. Install manometer using the built-in leveling bubble at your desired location (be sure you have enough tubing to reach the section of pipe in between the heater and barometric damper).
2. Using a 9/32 drill bit, drill a hole in the section of pipe in between the heater and the barometric damper.
3. Attach the pre-bent draft probe into the hole you drilled in the pipe (the probe should rest inside the chimney on the U-bend).
4. Follow manometer instructions to fill the gauge and zero out the reading (be sure that the tubing is disconnected from the manometer for this step).
5. Connect tubing to draft probe using the included fittings and push the tubing into the **LOW SIDE** of the manometer gauge. *Draft shown on the positive side of the gauge will indicate your negative (proper) reading of .02 cold, to .06 with a heated chimney.*

