



4109 Capital Circle

Janesville, Wisconsin 53546

New Heater Sales - 1-800-562-5504

Technical Phone Support - 1-888-370-6531

HI / MX PREHEATER RETROFIT - (SINGLE BLUE TERMINAL BLOCK)

Your kit includes:

- Retrofit preheater assembly.

Instructions:

1. Remove old preheater assembly.
2. Install retrofit preheater assembly.
3. Wire oil solenoid, air solenoid, and air proving switch as shown in the wire diagram.
4. Test fire heater and verify the burner is operating correctly.

